


$$\text{Permeability Coefficient} = \frac{\text{Amount of gas (cm}^3\text{) x tubing wall thickness (cm)}}{\text{Surface area of tubing I.D. (cm}^2\text{) x time (seconds) x pressure drop across tubing wall (cmHg)}}$$



**IMPORTANT:** Saint-Gobain Performance Plastics Corporation does not assume any responsibility or liability for any advice furnished by it, for the performance or results of any installation or use of the product or of any final product into which the product may be incorporated by the purchaser and/or user.

It is the user's responsibility to ensure the suitability and safety of Norton tubing for all intended uses. Laboratory, field or clinical tests must be conducted in accordance with applicable requirements in order to determine the safety and effectiveness for use of tubing in any particular application.